

# TRUNK ARMOR™

## APPLICATION INSTRUCTIONS

1. Carefully clean the trunk lid of your car and the contact foam or rubber feet of your trunk rack.
2. Test fit the trunk rack to your trunk so that you know where the film will be placed.
3. You can mark the area of installation on your trunk with masking tape so that you know where the Trunk Armor protective film will be placed.
4. There are a variety of Trunk Armor film strips/squares included in your kit. Use the pads which work best with the shape of the foam or rubber pads on your particular trunk rack.
5. Put 1 drop of a mild liquid soap or baby shampoo in the provided spray bottle, add water and shake to dissolve soap.
6. Using the spray bottle, liberally spray the trunk surface where the protective film will be placed.
7. Separate the film from its' protective backing and spray both sides of the clear film with the soap solution. Be careful not to allow the film to fold onto itself and be gentle as to not crease the film,
8. Place the wet film onto the wet area of your trunk's surface. The film will be able to slide back and forth while you adjust it to its' desired position.
9. Once the film is in the desired position, spray the surface of the film with the soap solution once more. Then, while holding the film in place with one hand, use your other hand to drag the squeegee (starting in the center of the film and pushing away from the center) to remove all of the excess soap solution and any "air bubbles" from underneath the film. Repeat this process over the entire film surface until all of the solution and air has been removed. (If any air bubbles remain after you have completed the application process, you may use a small pin to pierce the bubble)
10. Do not wash your vehicle for 24 hours after applying Trunk Armor. Do not use any pigmented or colored waxes on the film as it may discolor. You may cut the film into special shapes to fit your particular trunk rack if desired with a sharp, single razor blade.

**DO NOT USE ANY TYPE OF ADHESIVE TO ATTACH  
TRUNK ARMOR TO YOUR VEHICLE!**

**Bulk quantities of material available, please call for pricing!**

**Questions/Comments/Suggestions?**

**Trunk Armor, 1223 Long Run Road, White Oak, PA 15131 or call Toll Free: 1-877-832-6529**